

Fig. 1








Fig. 2



**Fig. 3A****Fig. 3B****Fig. 3C**


**Fig. 4**

Fig. 5




Fig. 6

47

51a

55

55

TV CHANNEL LIST

MAIN

OFF-TIMER ON

VOLUME

.....SILENCE

POWER

TERRESTRIAL

BS

CS

INPUT

1 NHK	3 NHK EDUCATION	4 NHON TELEVISION	6 TBS	8 FUJI TELEVISION	10 TELEVISION ASAHI	12 TELEVISION TOKYO
14 MX TELEVISION	42 TVK TELEVISION	38 TELEVISION SAITAMA	46 CHIBA TELEVISION			
101 NHK1	102 NHK2	103 NHK h	141 BS NIHON TELEVISION	151 BS ASAHI	161 BS-i	171 BS JAPAN
181 BS FUJI	191 WOWOW	200 STAR CHANNEL				
001 SPACETERIOR	011 CS NIHON	100 MULTICHANNEL ENTERTAINMENT				
VIDEO 1	VIDEO 2	VIDEO 3	VIDEO 4			

CLOSE

6/13

Fig. 7

47
51a
56

TV CHANNEL LIST		MAIN	OFF-TIMER ON	VOLUME	SILENCE	POWER
1 NHK	3 NHK EDUCATION	4 NIHON TELEVISION	6 TBS	8 FUJI TELEVISION	10 TELEVISION ASAHI	12 TELEVISION TOKYO
14 MX TELEVISION	42 TVK TELEVISION	38 TELEVISION SAITAMA	46 CHIBA TELEVISION			
101 NHK1	102 NHK2	103 NHK h	141 BS NIHON TELEVISION	151 BS ASAHI	161 BS-i	171 BS JAPAN
181 BS FUJI	191 WOWOW	200 STAR CHANNEL				
001 SPACE TERIOR	011 CS NIHON	100 MULTICHANNEL ENTERTAINMENT				
ASAHI.COM	PC Watch	ZDNet	Yahoo !	TECHSIDE	EXCITE	
VIDEO 1	VIDEO 2	VIDEO 3	VIDEO 4			

TERRESTRIAL

BS

CS

WWW

INPUT

CLOSE

Fig. 8






Fig. 9

47









51a

58

MEMORY STICK 100MSDCF 0000/0000 IMAGES OFF-TIMER ON VOLUME

SILENCE

POWER

<input type="checkbox"/> Cimg0005. jpg	<input checked="" type="checkbox"/> Cimg0005. jpg	<input type="checkbox"/> Cimg0005. jpg	<input checked="" type="checkbox"/> Cimg0005. jpg
			
<input checked="" type="checkbox"/> Cimg0005. jpg	<input checked="" type="checkbox"/> Cimg0005. jpg	<input checked="" type="checkbox"/> Cimg0005. jpg	<input checked="" type="checkbox"/> Cimg0005. jpg
			

CATCH

SLIDE SHOW

ALL CANCEL

DIRECTORY (-)

DIRECTORY (+)

SET

Control panel

# Fig. 10

47

51a

59

INTERNET

MAIN

OFF-TIMER ON

VOLUME IIIIIII

SILENCE

POWER

ADDRESS

<http://www.airbonet.com/>

SSL

LILST OF FAVORITES

Search by Google

SEARCH

TITLE	ADDRESS	DELETE	CHANGE
<input checked="" type="checkbox"/> TECHSIDE	<a href="http://www.techside.net/">http://www.techside.net/</a>		
<input checked="" type="checkbox"/> PC Watch	<a href="http://pc.watch.impress.co.jp/">http://pc.watch.impress.co.jp/</a>		
<input checked="" type="checkbox"/> ASAHICOM	<a href="http://www.asahi.com/">http://www.asahi.com/</a>		
<input checked="" type="checkbox"/> ZDNet	<a href="http://www.zdnet.co.jp/">http://www.zdnet.co.jp/</a>		
<input checked="" type="checkbox"/> EXCITE TRANSLATION	<a href="http://www.excite.co.jp/world/text/">http://www.excite.co.jp/world/text/</a>		
<input checked="" type="checkbox"/> POPULAR SCIENCE	<a href="http://www.so-net.ne.jp/psc/shop/">http://www.so-net.ne.jp/psc/shop/</a>		

RETURN	ADVANCE	STOP	READ AGAIN	HOME	ENLARGE CHARACTERS	REGISTER FAVORITES	SET
Control panel							

10/524354

# Fig. 11

47 } 51a } 60 }

VARIOUS SETTINGS

MAIN

OFF-TIMER ON

VOLUME 

IIIIIIII

SILENCE

POWER

SETTING OF TERRESTRIAL CHANNEL

SETTING STATE

DISPLAY CHANNEL	NAME OF BROADCASTING STATION	RECEPTION CHANNEL
1	NHK	1
2	TELEVISION SAITAMA	38
3	NHK EDUCATION	3

NEWLY REGISTER BROADCASTING STATION NAME


CHANGE BROADCASTING STATION NAME

SET

CANCEL

10/524354

# Fig. 12



10/524354

## DESCRIPTION OF REFERENCE NUMERALS

- 2 PRIMARY DISPLAY
- 3 SECONDARY DISPLAY
- 4 PEDESTAL
- 5 MEDIA RECEIVER
- 11 ACCESS POINT
- 22a MAIN TUNER
- 22b SUBTUNER
- 23 DIGITAL TUNER
- 28 SYSTEM CONTROLLER
- 43 SYSTEM CONTROLLER
- 46 LCD
- 47 TOUCH PANEL
- 51a DISPLAY/SENSOR UNIT
- 51b SENSOR UNIT
- 52 FINGER
- 53 SELECTION DISPLAY
- 54 MENU DISPLAY
- S1 TOUCH SENSOR DEVICE PORTION WITH FINGER
- S2 SHIFT TOUCHING FINGER
- S3 REMOVE FINGER FROM SENSOR DEVICE PORTION IN HIGHLIGHTED STATE OF  
BUTTON
- S4 REMOVE FINGER FROM SENSOR DEVICE PORTION IN NON-HIGHLIGHTED STATE  
OF BUTTON
- S5 SHIFT FINGER TO TOUCH PANEL (DISPLAY PORTION)